



HUNT ENGINEERING
Chestnut Court, Burton Row,
Brent Knoll, Somerset, TA9 4BP, UK
Tel: (+44) (0)1278 760188,
Fax: (+44) (0)1278 760199,
Email: sales@hunteng.co.uk
<http://www.hunteng.co.uk>
<http://www.hunt-dsp.com>



HUNT ENGINEERING

RemServe Server/Loader Example

For RTOS-32

Document Rev A
Server/Loader RTOS-32 RemServe Example Rev 4.11
J.Thie 27-01-04

COPYRIGHT

This documentation and the product it is supplied with are Copyright HUNT ENGINEERING 1999. All rights reserved. HUNT ENGINEERING maintains a policy of continual product development and hence reserves the right to change product specification without prior warning.

WARRANTIES LIABILITY and INDEMNITIES

HUNT ENGINEERING warrants the hardware to be free from defects in the material and workmanship for 12 months from the date of purchase. Product returned under the terms of the warranty must be returned carriage paid to the main offices of HUNT ENGINEERING situated at BRENT KNOLL Somerset UK, the product will be repaired or replaced at the discretion of HUNT ENGINEERING.

Exclusions - If HUNT ENGINEERING decides that there is any evidence of electrical or mechanical abuse to the hardware, then the customer shall have no recourse to HUNT ENGINEERING or its agents. In such circumstances HUNT ENGINEERING may at its discretion offer to repair the hardware and charge for that repair.

Limitations of Liability - HUNT ENGINEERING makes no warranty as to the fitness of the product for any particular purpose. In no event shall HUNT ENGINEERING'S liability related to the product exceed the purchase fee actually paid by you for the product. Neither HUNT ENGINEERING nor its suppliers shall in any event be liable for any indirect, consequential or financial damages caused by the delivery, use or performance of this product.

Because some states do not allow the exclusion or limitation of incidental or consequential damages or limitation on how long an implied warranty lasts, the above limitations may not apply to you.

TECHNICAL SUPPORT

Technical support for HUNT ENGINEERING products should first be obtained from the comprehensive Support section www.hunteng.co.uk/support/index.htm on the HUNT ENGINEERING web site. This includes FAQs, latest product, software and documentation updates etc. Or contact your local supplier - if you are unsure of details please refer to www.hunteng.co.uk for the list of current re-sellers.

HUNT ENGINEERING technical support can be contacted by emailing support@hunteng.co.uk, calling the direct support telephone number +44 (0)1278 760775, or by calling the general number +44 (0)1278 760188 and choosing the technical support option.

TABLE OF CONTENTS

THE REMSERVE EXAMPLE.....	4
COMPILING, LINKING AND RUNNING THE EXAMPLE	5
SERVER/LOADER EXECUTABLE	5
RUNNING THE EXAMPLE	5
COMMAND LINE.....	6
THE SERVER/LOADER COMMAND LINE.....	6
FLOPPY ACCESS.....	6
TECHNICAL SUPPORT	7

The Remserve Example

The remote example is a simple Server/Loader example program that shows how to boot a 2-board network where each board has 1 processor module, and the two boards are connected via Inter-Board Connectors (using **two** channels). The example shows how 1 of the boards can be 'remote'. Keyword 'remote' identifies a board that is non-local, for example an embedded board or a board that is in another PC. The processor on the 'remote' board will get booted via the local board. In addition, this example shows how a 'remote' DSP can still use 'stdio' functions as long as there's an Inter-Board Connector channel available for it. The booted programs don't do a lot, they just pass a small message between them, and then the programs exit. (Plural is used, as 1 program is loaded to the first processor ('mod1_h4.out') and another to the second processor ('mod2_h4.out').)

(This example will **not** work with TIM-40 carrier boards such as the HEPC2E, HEPC3, HEPC4 or HECPCI1. It will also **not** work with the HEPC6, a one 'C6x processor board.)

Compiling, linking and running the example

Server/Loader executable

The Server/Loader executable is delivered as a 'sl.exe' file, plus standard configuration files ('sl.cfg' and 'pcdemo.cfg'). The Server/Loader RTB file ('sl.rtb') is included as well. For this example, you can simply use the RTB file. The files are all located in the 'hesl\bin\rtos32' sub-directory of your API&Tools installation (default 'c:\heapi'). An environment variable 'HEAPI_DIR' will point to your installation directory (this has been set up by the API&Tools installation program). Environment variable 'HESL_DIR' will point to the 'hesl' sub-directory within your API&Tools installation directory.

Running the example

To run the example, prepare a floppy disk and insert it into the 'a:' drive. Open a DOS-box, and change directory to the '2boards\remserve\rtos32' directory. Then type:

```
bootdisk $(HESL_DIR)\bin\rtos32\sl a:
```

Next, copy the network file and *.out file to the floppy disk as well:

```
copy network a:
copy mod1_h4.out a:
copy mod2_h4.out a:
```

if you use HERON4's in slot 1 and 2 of your HEPC9, or

```
copy network a:
copy mod1_h2.out a:
copy mod2_h2.out a:
```

if you use HERON2's in slot 1 and 2 of your HEPC9.

(To help you start up faster, we have included 8 prepared out files, 4 for use with HEPC9, and 4 for use with HEPC8, in the rtos32 sub-directory. But usually the two *.out files must first be created using Code Composer Studio. Please refer to the document in the lower (upper?) directory how to do this.) After completion, remove the floppy disk; insert it into the target machine's floppy drive. Reboot. The machine should now boot from disk. You should see something that ends like:

```
Entering Server mode.
Entering Server mode.
  first HERON module has started running
  second HERON module has started running
HERON module id 2 has replied
Bitwise echo test completed successfully.
Leaving server mode.
Leaving server mode.
Serving 2 nodes completed.
```

The Server/Loader command line

The Server/Loader uses a command line so that a user can specify the name of a network file and a number of parameters. The most common parameters are `-r`, (reset), `-l` (load), `-s` (serve) and `-v` (verbose). The Server/Loader RTB file in `$(HESL_DIR)\bin\rtos32` has a default command line of:

```
CommandLine "a:\sl.exe -rlsv a:\network"
```

As you can see, with this command line the Server/Loader will expect to find a network description file on the floppy drive. By default, this RTB file will reset the system, boot all processors, and then serve standard I/O requests (`printf`, `fwrite`, etc) coming from the first processor in the system. The verbose option will cause booting information to be show on the screen.

There may be situations where this command line is not what you want. Therefore the Server/Loader is also delivered as an exe file ('sl.exe') plus two configuration files ('sl.cfg' and 'pcdemo.cfg'). You can now change configuration parameters as needed.

Floppy access

To access files on a floppy disk, not only do you need to link with RTFILES-32 libraries, you also need to allocate a DMA buffer for the floppy driver in your configuration file. We added the following line to the 'sl.cfg' configuration file:

```
Locate Nothing FloppyDMA HighMem 18k 32k ReadWrite
```

Please refer to the RTOS-32 manual (Part III, ch. 7, page 300) for more information.

Technical support for HUNT ENGINEERING products should first be obtained from the comprehensive Support section www.hunteng.co.uk/support/index.htm on the HUNT ENGINEERING web site. This includes FAQs, latest product, software and documentation updates etc. Or contact your local supplier - if you are unsure of details please refer to www.hunteng.co.uk for the list of current re-sellers.

HUNT ENGINEERING technical support can be contacted by emailing support@hunteng.co.uk, calling the direct support telephone number +44 (0)1278 760775, or by calling the general number +44 (0)1278 760188 and choosing the technical support option.